

LUCASOL™ One Step™ EYESHIELDS CLEANING/DISINFECTION INSTRUCTIONS

FOLLOW THESE DIRECTIONS FOR PROPER CLEANING/DISINFECTION OF EYESHIELDS

1 Add 3/8 oz. (3 pumps from the LUCASOL™ measuring pump) LUCASOL™ One Step™ to Sanitizer Jar then fill with water to fill-line on Sanitizer Jar.

2 Use Quat Test Strip to ensure proper mixture. Proper mixture requirements are a minimum of 700 ppm.

3 Remove/wipe excess dirt and debris from Eyeshields. Place Eyeshields in Sanitizer Jar.

4 Soak Eyeshields for 10 minutes to achieve 100 % disinfection.

5 After 10 minute soak, remove Eyeshields from Sanitizer Jar. Dry Eyeshields with a clean anti-bacterial Micro Suede Towel. Store disinfected Eyeshields in a clean, dry container.

